



Luftwaffe's Sabres Pt.I





Luftwaffe's Sabres Pt.I



Now that we have deciphered this mystery for you, it is time to start building. Happy modeling.

UPPER COLORS, RAL 6014 Gelboliv, RAL 7012 Basaultgrau, LOWER COLORS RAL 7001 Silbergrau. If

the nose section of the a/c you are modeling is Green, the following colors apply:
UPPER COLORS FS 34079 Forrest Green, RAL 7015 Schiefergrau, LOWER COLOR PRU BLUE.

Copyright © 12/2004